### MEASURING AND MOULDING REQUIREMENTS FOR ORDERING PROFIMATS FROM HAMAT B.V.

# What basic information is necessary for measuring:

- The name, address and telephone number of the subcontractor;
- Type of mat, desired inlay, colour code(s) and any accessories (ramped edge, etc.);
- Sketch and/or photo of the entrance(s) to be measured;
- Completion date or agreed opening date of entrance(s) in question;
- Any specific instructions.

#### **Conditions:**

- There must be full and complete edging around the well;
- The subfloor must be flat and even;
- The well /subfloor must be dry and clean;
- The well in question must be the correct depth;
- Any skirting boards/tiles/radiators on the wall must be mounted before measuring;
- The entrances to be measured must be clear (no building materials and/or construction waste);
- The entrance area must be completely free of obstructions (no building materials, scaffolding, or construction waste, etc.) to be able to measure and install the mat.

It is important to note the following for supply of the entrance mats, because the mats are specially made to measure.

#### In the case of a recessed well:

- The entrance mat is supplied rolled up. Take care when cutting away the protective cover so as not to damage the mat;
- Unroll the entrance mat carefully along the barrel length. It is not necessary to have a fixed attachment to the subfloor.

## On the pavement:

- The entrance mat is supplied rolled up. Take care when cutting away the protective cover so as not to damage the mat;
- It is optional to have a ramped edge attached to the mat. This is the 'start' of the mat. The other side with the U-frame must be flush with the doorframe. (This only applies to the Profibrush);
- Unroll the entrance mat carefully along the barrel length.

# With ramped edges surrounding the mat:

- Attach the ramped edges to the subfloor. this creates a 'well';
- The entrance mat is supplied rolled up. Take care when cutting away the protective cover so as not to damage the mat;
- Unroll the entrance mat carefully along the barrel length. It is not necessary to have a fixed attachment to the subfloor.

### Additional points for consideration:

- If the well has not been properly prepared, Hamat reserves the right to return to Genemuiden and to charge for travel time and costs incurred;
- If the well situation has changed upon installation, necessitating the mat to be altered, extra hours will be charged;
- If the entrance cannot be measured or moulded properly due to too many people walking through it, we must be notified so that we can make an appointment outside working hours in consultation;
- For newbuild projects, it is important that a photo is supplied showing the status of the entrance;
- The Profi mats are supplied rolled up. The Profi Duo consists of panels and cannot be rolled up:
- To be eligible for our guarantee, the surface of the well in question must be completely flat;
- A cost estimate can be provided prior to measuring, because measuring is not without obligation;
- It is desirable to have a contact person present at the site at all times.